

BaByliss[®] **PRO**
S T Y L I S T T O O L S



**TITANIUM
STRAIGHTENER**

BAB2091BU

TITANIUM STRAIGHTENER

This heavy-duty, professional straightener delivers fast, effective results. Titanium plate technology gives outstanding heat transfer and lasting smoothness for super sleek styles. Active ionic conditioners smooth the hair cuticle for instant shine.

Features:

- True titanium plate technology gives advanced heat transfer for smooth, lasting results
- Active ionic conditioning for instant shine
- 30mm wide plates for fast styling on thicker and longer hair
- Advanced Ceramics™ for ultra-fast heat up and regulated heat stability
- 5 digital temperature settings 150°C - 230°C for all hair types
- Hard-wearing, durable design built for reliable, continuous salon use
- Heat wrap
- Salon length 2.7m swivel cord

SAFETY CAUTIONS

- This appliance should only be used as described within this instruction booklet. Please retain for reference.

IMPORTANT CHILD SAFETY

WARNING! Polythene bags over a product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

WARNING! THIS APPLIANCE GETS HOT!

- **ALWAYS** keep out of reach of children (during and after use and whilst cooling).

- This appliance should not be used, cleaned or maintained by children.
- Always take extra care if used on children or near children.
- Do not use on very young children.

IMPORTANT SAFETY

WARNING! Do not use this appliance near water contained in basins, bathtubs or other vessels.



- Do not use the appliance in the bathroom.
- Do not immerse the appliance in water or other liquids.
- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged, or if the appliance has been dropped. In the event of damage, contact the Conair Customer Care Line (refer to 'UK After Sales Service' section for further information).
- Do not use the appliance if the lead is damaged. In the event of lead damage, discontinue use immediately. If the lead is damaged it must be replaced by the manufacturer. Return the appliance to the Customer Care Centre (refer to 'UK After Sales Service' section for further information). No repair must be attempted by the customer.
- Do not leave the appliance unattended when switched on or plugged in.
- During use do not place the appliance on any heat sensitive surface, even when using the heat wrap provided.
- Take care to avoid the hot surface of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.
- This appliance should not be used by adults whose reduced physical, sensory or mental capabilities, or whose lack of experience and knowledge, might cause

a hazard, unless they have been correctly instructed to understand the safe use and hazards involved and are adequately supervised.

- After use, do not coil the lead around the appliance as this may cause damage. Instead, coil loosely by the side of the appliance.
- This appliance complies with the requirements of Directives 2004/108/EC (Electromagnetic Compatibility) and 2006/95/EC (Electrical Safety of Domestic Appliances).

TEMPERATURE SETTING GUIDE

There are 5 temperature settings to select from (150°C-230°C) for styling various hair types. Use the table below as a guide to find the correct temperature for your hair category. Always start with a lower temperature and increase gradually if required.

Hair Type Description	Very Fine, Fragile Hair	Regularly Coloured or Highlighted Hair	Normal Textured Hair	Naturally Curly or Wavy Hair	Thick or Coarse Hair
Recommended Temperature Setting	150°C	170°C	190°C	210°C	230°C

GENERAL OPERATING INSTRUCTIONS

- Ensure hair is dry and combed through.
- Press the '(I/O)' button to switch the styler on.
- The styler automatically heats up to 150°C.
- Using the temperature buttons (+/-) you can increase or decrease the temperature.

NOTE: There may be a slight buzzing sound from the ionic port as it releases the ions. This is normal.

- After use, press the '(I/O)' button to switch off and unplug the styler.
- Immediately wrap in the heat mat provided and allow to cool.
- Allow the styler to cool down fully before storing away.

Heat Protection Wrap

The straightener comes with a heat protection wrap for use during and after styling. During use do not place this appliance on any heat sensitive surface, even when using the heat wrap provided. After use, switch off and unplug the appliance. Immediately wrap the appliance in the heat wrap provided and allow to fully cool down. Continue to keep it out of the reach of children as it will remain hot for several minutes.

CLEANING & MAINTENANCE

- In order for your styler to retain it's top performance it is important to make sure there is no product build up on the plates. This will ensure the plates always glide smoothly through the hair.
- When the styler is completely cool and unplugged, use a damp cloth over the surface of the plates to wipe away any styling product.
- Keep the power cord away from the hot plates at all times.
- Before storing away, always allow the plates to cool down.
- To prevent cord damage, never wrap the cord around the styler.


UK GUARANTEE

This BaByliss PRO appliance is guaranteed for salon use for 6 months. This guarantee covers defects under normal use from date of purchase and ceases to be valid in the event of alteration or repair by unauthorised persons. If the appliance does not perform satisfactorily due to defects in materials or manufacture, it will be repaired or replaced through Conair UK After Sales Service. The Conair Group Ltd reserves the right to amend terms and specifications without prior notice.

This guarantee in no way affects your statutory rights.

SAFE DISPOSAL



The  symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be handed to an appropriate collection point for the recycling of Electrical and Electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.

UK AFTER SALES SERVICE

For further advice on using the appliance or should you need to return your product, please contact the Conair Customer Care Line on 03705 133191 (09:00 to 17:00 Monday to Friday) or email your enquiry to ukinfo@conair.com.

The return address is:
Customer Care Centre,
Conair Logistics
Unit 4, Revolution Park
Buckshaw Avenue
Buckshaw Village
Chorley
PR7 7DW


Please enclose your returns number, name and address details, together with a copy of proof of purchase and details of the fault.

UK WIRING INSTRUCTIONS

The wires in the mains lead are coloured in accordance with the following code:

- BLUE = NEUTRAL
- BROWN = LIVE

As the colours of the wire in the mains lead of this appliance may not correspond with the colour marking identifying the terminals on your plug, proceed as follows:

- The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N.
- The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L.
- Neither the BLUE nor BROWN wires should be connected to the terminal which is marked with the letter E or the  symbol.

This appliance is supplied fitted with a BS1363 mains plug and a BS1362 5A fuse. If this plug is removed from the appliance please ensure it is disposed of safely as a disconnected plug is dangerous if reconnected to the mains. If any other type of plug is used, a 5A fuse must be fitted.